





# Loading Ramp Setup & Removal Instructions



## Note:


These instructions have been optimized for digital devices. Please consider the environment before printing.

# Loading Ramp Setup Instructions



## Step 1


Slide ramp towards you until leg assembly is clear of the trailer



## Step 2


Unfold leg assembly until legs rest against stop blocks and lock into leg assembly

# Loading Ramp Setup Instructions



## Step 3


Slide ramp toward you until apron rests flat on trailer floor



## Step 4


Ensure rail ends are touching end of trailer and entire apron is inside trailer

# Loading Ramp Setup Instructions



## Step 5


Place legs on firmly on ground



## Step 6


Unfold ramp, resting it on ground

# Loading Ramp Removal Instructions



## Step 1


Fold the bottom portion of the ramp until it rests on the top half of the ramp.



## Step 2


Lift the ramp off of the ground

# Loading Ramp Removal Instructions



## Step 3

Slide ramp into trailer until apron rests flat on trailer floor




## Step 4

Raise yellow bar to unlock leg assembly. Fold leg assembly. Slide rest of ramp into trailer.

# Loading Ramp Information

## Ramp Terms:



## Improper vs. Proper Usage:

**✗ Incorrect Usage:**  
Downhill from hand-truck



**✓ Correct Usage:**  
Uphill from hand-truck



## Ramp Placement Reminder:

The ramp must NEVER be packed behind the bulkhead with your personal belongings and should be the last item loaded on the trailer.